



Guitar Trainer CD-GT1

CD-GT1 makes practising a pleasure – simply insert your favourite CD, connect your guitar and away you go. Even complicated riffs and licks are easy when you mark a section and play it back repeatedly without interruption. You can reduce the playback speed by up to half without changing the pitch. Or, if the key doesn't suit, you can change the pitch by up to 6 semi-tones and 50 cents without affecting tempo. There's even a built in tuner to help you keep your strings in tune.

Practice makes perfect, but only with the right sound. That's why 15 clean and distortion sounds plus 13 vocal effects are already included in the CD-GT1. Vocals? We'd almost forgotten: Instead of a guitar, you can also connect a microphone and sing along to the CD. If you don't have your



Main features

CD player and guitar/mic pre amplifier with effects unit in one
 Playback modes: Single, Continuous, Single Loop, All Loop and Seamless In-Out Loop
 Slow Speed Audition (-8, -16, -32, -50%) allows tempo control without affecting key
 Key control function (± 6 semitones and ± 50 cents) allows key change without affecting tempo (not in conjunction with SSA function)
 Pitch control (0 to -50% in 1% steps) changes tempo and key together

Cue point memory (for instant location of last play start point)
 Flash start: Seamless locate and play from the cue point
 Switchable Guitar/Mic input with level control
 Built-in effects: 15 distortion sounds, 15 clean sounds, 13 vocal effects
 Up to 10 user effect settings storable
 Built-in chromatic tuner (435-445Hz in 1Hz steps); auto or manual tuning selectable
 Phones and Line output with level control

Foot switch input for instant start or switching between effect settings
 10 seconds anti-shock memory
 Hold switch to lock CD-GT1's controls & keys
 Two options of power supply: batteries or optional AC adapter
 Optional accessories: PS-PS5 AC adapter, RC-30P Footswitch controller



Guitar Trainer CD-GT1

practice song on CD, you can use the additional stereo input to connect a cassette recorder, an MP3 player or another instrument. And of course there's also the usual stereo output, which you can use to connect the trainer to a stereo system or mixer desk.

And because guitarists normally only have two hands, an optional footswitch is available for starting and stopping the CD player or switching effects. Who said practising can't be fun?!



The clear display provides all essential information for the CD playback and menu settings. Navigation is a snap with the large rocker switch. It's easy and convenient to use, whether you want seamless repetition, to cue to the last start point or select effects.

SPECIFICATIONS

Types of disc read.....	8cm/12cm CD
Audio channels.....	2 channels
Frequency response.....	20Hz - 20kHz ±1.0dB
Dynamic range.....	>98dB
Signal-to-noise ratio.....	>88dB
Total Harmonic Distortion.....	<0.01% (1kHz)


ANALOGUE INPUTS AND OUTPUTS

Guitar/Mic input.....	6.3-mm TRS jack, unbalanced
Nominal input level.....	Guitar: -15dBV, Mic: -40dBV
Stereo Line input.....	3.5-mm stereo jack
Nominal input level.....	-10dBV

Stereo Line output.....	3.5-mm stereo mini jack
Nominal input level.....	-10dBV
Maximum output level.....	0dBV (1Vpp)
Nominal impedance.....	1k ohm
Headphone output.....	3.5-mm stereo mini jack
Maximum output power.....	18mW (at 32 ohm)

POWER SUPPLY AND OTHER SPECIFICATIONS

Voltage requirements.....	DC 9V via optional AC adapter PS-PS5
.....	or four AA batteries
Power consumption.....	7W (with PS-PS5)
Dimensions (W x H x D).....	232 x 138 x 40mm
Weight.....	0.553kg



TEAC CORPORATION	3-7-3, Nakacho, Musashino-shi, Tokyo 180-8550, Japan.....	Tel: +81-422-52-5082
TEAC AMERICA, INC	7733 Telegraph Road, Montebello, CA 90640 USA.....	Tel: +1-323-726-0303
TEAC CANADA LTD	5939 Wallace Street, Mississauga, Ontario L4Z 1Z8, Canada.....	Tel: +1-905-890-8008
TEAC MEXICO, SA de CV	Campeinos N°184, Colonia Granjas Esmeralda, Delegacion Iztapalapa, CP 09810 Mexico DF... Tel: +52-(5)-658-1943	
TEAC UK LIMITED	5 Marlín House, The Croxley Centre, Watford, Herts., WD1 8YA, UK.....	Tel: +44-1923-819630
TEAC DEUTSCHLAND GmbH	Bahnstrasse 12, 65205 Wiesbaden-Erbenheim, Deutschland.....	Tel: +49-611-71580
TEAC FRANCE SA	17 Rue Alexis-de-Tocqueville, CE 005 92182 Antony Cedex, France.....	Tel: +33-1-42.37.01.02
TEAC ITALIANA SpA	Via C. Cantu 11, 20092 Cinisello Balsamo, Milano, Italy.....	Tel: +39-2-66010500
TEAC AUSTRALIA PTY LTD	106 Bay St., Port Melbourne, Victoria 3207, Australia.....	Tel: +61-3-9646-1733

www.teac.co.jp
www.tascam.com
www.tascam.com
www.tascam.co.uk
www.tascam.de
www.tascam-europe.com
www.teac.it
www.teac.com.au

