

ENGINEERED BY
TASCAM | DESIGNED BY
mixwell

Co-designed by Mixwell and Tascam DJ, the **CD-DJ1** is one of the smallest tabletop CD/MP3 players available for professional DJs.

Although it may be small in size, it's big on powerful features, including seamless loops, hot starts, master tempo and more. And with its low profile, ultra-compact size, there's no need to lug a big, traditionally heavy tabletop CD player around.

The **CD-DJ1** is also compatible with Tascam's award winning TT-M1 Scratch Controller. Once connected to the **CD-DJ1**, you can use your existing turntable and any vinyl record to mix and scratch MP3s and CD audio without the need of any special audio hookups, coded vinyl or computer.



- ▶ Unique ultra-compact size
- ▶ Anti-shock memory
- ▶ MP3 playback
- ▶ Supports CD Text and ID3 tag for MP3
- ▶ Seamless loop
- ▶ Two hot start points
- ▶ Key Original (master tempo)
- ▶ TT-M1 "Turntable Magic" connector
- ▶ Dimensions (W x H x D): 155 x 60 x 275 mm
- ▶ Weight: 1 kg



© 2006 TEAC Europe GmbH All Rights Reserved. All specifications are subject to change without notice. All trademarks are property of their respective holders. Visit www.tascam-europe.com or www.tascam.com for most up-to-date information.



www.tascam-europe.com

TEAC Europe GmbH Bahnstr. 12, 65205 Wiesbaden, Germany
TEAC UK Ltd. Unit 19 & 20, The Courtyards, Hatters Lane, Watford, Hertfordshire WD18 8TE, UK



CD-X1500



CD-X1700

- ▶ Seamless loop
 - Repeatedly playback a section marked with A and B points
- ▶ 3 flash start/cue points
 - Instantly start playback at a cue point
- ▶ Stutter play
 - At a cue point, hold down cue key as long as playback shall be performed
- ▶ Auto cue
 - Automatically find the audio beginning of a song
- ▶ Auto ready
 - Pause at the beginning of the next track
- ▶ $\pm 0, 8, 16, 32$ and 100% tempo control
 - Set the song tempo with the Tempo slider or by tapping on the TAP key
- ▶ Key Original function
 - Prevents original key from being affected by tempo changes
- ▶ Pitch bending function
 - Change the playback tempo momentarily with the wheel
- ▶ $\pm 16\%$ key control
 - Use the wheel to change the key without affecting the tempo
- ▶ BPM count with Tap key
 - Shows the manually tapped BPM value
- ▶ Scratch function
 - Use the wheel for scratching like with analogue turntables
- ▶ Brake function
 - Same effect like switching off an analogue turntable
- ▶ TT-LINK®-Accessory connector for TT-M1 CD Scratch Controller
 - Scratch, pitch-bend, back-spin and otherwise control your CDs like using vinyl
- ▶ Filter effect
 - Use the wheel to affect the cutoff frequency
- ▶ Continuous play, single play, and up to 30 tracks program play
- ▶ Track memory
 - Stores various playback settings for up to 100 tracks
- ▶ Fader start
 - Start playback from an external device which supports the fader start function
- ▶ Relay play
 - Continuous playback over both units
- ▶ Anti-shock memory
- ▶ Digital output
- ▶ Supports CD-R/RW discs
- ▶ Compact 2U controller size
- ▶ Two integrated samplers
 - 10 seconds sampling on each unit
 - Reverse playback
 - $\pm 32\%$ pitch control
 - Sampler level control
- ▶ MP3 playback
 - Play CDs containing MP3 files (MPEG 1 audio layer 3)
 - Up to 254 directories, up to 255 files per CD
 - 32-190kbps, constant bit rate
 - Pitch bending and tempo changes on MP3 songs
- ▶ On-board digital effects
 - Echo, Flanger and Filter effects syncable to BPM; Filter auto and manual modes
- ▶ Seamless loop
 - Repeatedly playback a section marked with A and B points
- ▶ 3 flash start/cue points
 - Instantly start playback at a cue point
- ▶ Reverse play
- ▶ Stutter play
 - At a cue point, hold down cue key as long as playback shall be performed
- ▶ Auto cue
 - Automatically find the audio beginning of a song
- ▶ Auto ready
 - Pause at the beginning of the next track
- ▶ $\pm 0, 8, 16, 32$ and 100% tempo control
- ▶ Key Original function
 - Prevents original key from being affected by tempo changes
- ▶ Pitch bending function
 - Change the playback tempo momentarily with the wheel
- ▶ $\pm 16\%$ key control
 - Use the wheel to change the key without affecting the tempo
- ▶ BPM counter
 - Shows the track's BPM value or the manually tapped BPM value
- ▶ Scratch function
 - Use the wheel for scratching like with analogue turntables
- ▶ Brake function
 - Same effect like switching off an analogue turntable
- ▶ TT-LINK®-Accessory connector for TT-M1 CD Scratch Controller
- ▶ Continuous play, single play, and up to 30 tracks program play
- ▶ Track memory
 - Stores settings for up to 100 tracks
- ▶ Fader start
- ▶ Relay play
- ▶ Anti-shock memory
- ▶ Digital output
- ▶ Supports CD-R/RW discs
- ▶ 3U controller size

© 2006 TEAC Europe GmbH All Rights Reserved. All specifications are subject to change without notice. All trademarks are property of their respective holders. Visit www.tascam-europe.com or www.tascam.com for most up-to-date information.



www.tascam-europe.com

TEAC Europe GmbH Bahnstr. 12, 65205 Wiesbaden, Germany

TEAC UK Ltd. Unit 19 & 20, The Courtyards, Hatters Lane, Watford, Hertfordshire WD18 8TE, UK