

Enable User Mode by holding SEL + PAN when waking up the US-2400.

User Mode provides 8 banks of Continuous MIDI Controllers, output by the faders and encoders. Everything is on the first MIDI port. Each bank is on its own midi channel (bank 1 = ch1, bank2 = ch2, etc....). The controllers have a 1 to 1 relationship with the channels (channel strip 3 = controller 3, etc...). The Aux Select section selects which bank the encoders send (CHAN = bank 0, PAN = bank 1, Aux1-6 = bank 2-8). For the faders, Bank+/- keys select which bank the faders control (displayed on the LEDs under the master fader). It is possible to have both encoders and faders assigned to the same bank. Buttons work as in Native mode except the channel section buttons are latched.